

Gen II Backgauge Programming Guide

Piranha
P.O. Box 457
Hutchinson, Ks 67504

Voice (800) 338-5471
Fax (620) 669.8964
Web Site www.piranhafab.com

No part of this manual may be stored in a retrieval system, transmitted, or, reproduced in any way. Including but not limited to photocopy, photograph, and magnetic or other record without the prior agreement and written permission of Mega Manufacturing Inc.

PN: -1
GEN II-X Manual

Gen II Backgauge Programming Guide

Safety

Safety must be a primary concern. When operating or performing maintenance procedures, follow all standard safety guidelines. Do not wear loose fitting clothing or any articles that may be pulled into any moving parts.

Be sure that when operating the equipment, all safety devices operate properly. Never under any circumstances disable, remove, or alter the original configuration of the safety system.

Should any component of the safety system become inoperable, immediately discontinue operation, and notify a supervisor.

- ! **NEVER** place fingers, hands, or any other body part in or under the ram area or other moving mechanisms.
- ! Proper eye protection must be worn at all times when operating the machine.
- ! Always insure that the machine is turned **OFF** before changing the tooling.

Read and understand this manual prior to operating the machine.

The area around the Piranha Press Brake should be well lighted, dry, and free of obstacles.

The Piranha Press Brake is designed for single person operation only.

Always insure that all tooling is properly secured in position before starting any operation.

When servicing the machine always practice standard lockout/tag-out procedures to avoid personal injury.

Qualified maintenance personnel only should perform service operations on the Piranha Press Brake.

NOTE: The Run/Program keyswitch provides security for choosing initiation means and operation modes that can be supervised by the user, in accordance with ANSI B11.3 standards.

WARNING:

- Ensure that no part of the Finger Assembly interferes with the press brake tooling
- All backgauge adjustments must be made from the rear of the machine.
- Do not reach across the press brake tooling or through the bed and ram.
- Severe injury or death may result if these procedures are not followed

Gen II Backgauge Programming Guide

Programming a Simple Job with Gen II Back Gauge

1. Start Press Brake motor by depressing the green **START** button.
2. Caution – Make sure that the back gauge area has been cleared of all obstructions.

```
X-axis Start Up  
Press ENTER for X-  
Axis to find CAL  
Switch.
```

```
JOB#-XXXXXXX  
BEND XX/XX C:000000  
Y=XX.XXXXin X=XX.XXX  
HAND-RUN1
```

3. Press **ENTER** for calibration routine to find 24.000” Home Switch Reference screen for key switch in “RUN” position, this is the standard RUN Screen
4. Rotate keyed Programming switch to “**PROG**” (program) Mode.

```
HAND          RUN1  
>1-TEACH/EDIT JOB  
  2-SET BEND NUMBER  
  3-MACHINE SETUP
```

5. Press **#1** on keypad.

```
>1. TEACH NEW JOB  
  2. EDIT CURRENT JOB  
  3. SAVE CURRENT JOB  
  4. DEL CURRENT JOB
```

6. On new screen, ensure arrow is on #1 (>1), press **ENTER**. Or Press **1**

```
TEACH NEW JOB:  
ENTER NEW JOB#  
  
XXXXXXX
```

7. Key in the desired job number and press **ENTER**.

Gen II Backgauge Programming Guide

```
TEACH NEW JOB:  
ENTER JOB DESC  
  
XXXXXXXX
```

8. Press **CLR** and key in a job description and press **ENTER** (To bypass description screen, press CLR (clear) then ENTER)

```
TEACH NEW JOB:  
PRESSING SPEED  
  
100_ %
```

9. Key in Pressing Speed or use **↑and ↓** to desired value and press **ENTER**.

```
TEACH NEW JOB:  
FINISHING SPEED  
  
100_ %
```

10. Key in Finishing Speed or use **↑and ↓** to desired value and press **ENTER**.
NOTE: Finishing Speed is an option that must be turned on by Piranha, in order to be used. This field shows whether this option is turned on or not.

```
TEACH NEW JOB:  
PROCEED TO BENDS?  
YES or NO
```

11. Press “**YES**” button to proceed to bends.

```
TEACH NEW JOB:  
TEACH NEW BEND 1  
FLANGE DIMENSION  
XX.XXX_ In.
```

12. Key in desired FLANGE DIMENSION and press **ENTER**.
FLANGE DIMENSION is the desired flange length, this can be inside or outside flange dimensioning.


Gen II Backgauge Programming Guide

```
TEACH NEW JOB:  
USE MODE KEY FOR +/-  
BEND ALLOWANCE  
XX.XXX_ In.
```

13. Key in desired BEND ALLOWANCE, use **MODE** key to toggle between plus and minus bend allowance, and press **ENTER**.


BEND ALLOWANCE is the distance that takes into account material thickness and stretch or shrink. Typically, if an outside flange dimension is used, then this number should be negative. Typically, if an inside flange dimension is used, then this number should be positive. The control adds BEND ALLOWANCE to FLANGE DIMENSION yielding the correct back gauge position for the bend's centerline. See Fig. 7 on the next page:

Gen II Backgauge Programming Guide



TEACH NEW JOB:
TEACH NEW BEND 1
RETRACT DISTANCE
XX.XXX_ In.

Key in desired **RETRACT DISTANCE** and press **ENTER**.
RETRACT DISTANCE is simply the distance that the back gauge retracts, when the ram is at the pinch point. See Fig. 4 Below:




TEACH NEW JOB:
TEACH NEW BEND 1
X DWELL TIME
X.X_ Sec.

14. Key in desired **X DWELL TIME** and press **ENTER**


Gen II Backgauge Programming Guide

X DWELL TIME is the amount of time that the back gauge stays at the retracted distance after the ram reaches the top of stroke, before it moves into the next bend position. See Fig. 6 below:



```
TEACH NEW JOB :
TEACH NEW BEND 1
TOS POSITION
XX.XXXX XX.XXXX
```

15. Key in desired Top of Stroke target position and press **ENTER** –or– Move press ram to desired position, then press **JOB LEARN** button to save position and press **ENTER**. See Fig. 2 below:




```
TEACH NEW JOB :
TEACH NEW BEND 1
SPEED CHG. POS.
XX.XXXX XX.XXXX
```

16. Key in desired Speed Change target position and press **ENTER** –or–

Gen II Backgauge Programming Guide

Move press ram to desired position, then press **JOB LEARN** button to save position and press **ENTER**. See Fig. 3 below:




TEACH NEW JOB :
TEACH NEW BEND 1
PINCH POINT POS.
XX.XXXX XX.XXXX

17. Key in desired **PINCH POINT** target position and press **ENTER** –or– Move press ram to desired position, then press **JOB LEARN** button to save position and press **ENTER**. **PINCH POINT POS.** is the Ram Position at which the material is engaged/clamped and the back gauge is to move back by its retract distance.

NOTE: PINCH POINT is only used for GEN II+X Back Gauge Machine


See Fig. 4 below:



TEACH NEW JOB :
TEACH NEW BEND 1
BOS POSITION
XX.XXXX XX.XXXX

Gen II Backgauge Programming Guide

18. Key in desired Bottom of Stroke target position and press **ENTER** –or– Move press ram to desired position, then press **JOB LEARN** button to save position, use **RAM UP** to release material, and press **ENTER**. See Fig. 5 below:



TEACH NEW JOB :
TEACH NEW BEND 1
RETURN SPEED MODE
HIGH

19. Select Return Speed mode (**HIGH**, **LOW/HIGH**, or **LOW**) by toggling the **UP** or **DOWN** arrows and press **ENTER**.
- HIGH** – Retracts the ram at full retract speed
 - LOW/HIGH** – Retracts the ram from bottom of stroke to speed change in pressing speed, then at full retract speed to the top of stroke
 - LOW** – Retracts the ram at pressing speed all the way to top of stroke

Gen II Backgauge Programming Guide

```
TEACH NEW JOB:
TEACH NEW BEND  1
BEND TONNAGE
100_ %
```

20. Set Bend Tonnage (if equipped), by typing and using arrows, and press **ENTER**.

```
TEACH NEW JOB:
TEACH NEW BEND  1
CONTINUE WITH JOB?
YES or NO
```

21. To program additional bends, press **YES** and repeat steps 7-15.
22. If additional bends are not required, press **NO**.

```
>1. TEACH NEW JOB
  2. EDIT CURRENT JOB
  3. SAVE CURRENT JOB
  4. DEL CURRENT JOB
```




23. Press **#3** to save job.
24. Rotate Keyed Programming switch to “**RUN**” Mode and cycle the press.
25. If the Back Gauge is presently not located in the correct bend position, the pedestal will show the following message:
INSURE BACKGAUGE IS
UNOBSTRUCTED!
PRESS ENTER TO MOVE
INTO POSITION.
27. Press **ENTER** and the back gauge will move to the required bend position, and you can continue

Gen II + X Go To Back Gauge Function


1. Make sure that Back Gauge area is cleared of all obstructions.
2. Flip key switch to **PROG**
3. Type “4” for **GOTO BACKGAUGE** or use ↓ to move “>” next to this one and press **ENTER**.
4. Type in desired back gauge position and press **ENTER**.
5. Back Gauge moves to specified position

Gen II Backgauge Programming Guide



Figures-





Gen II Backgauge Programming Guide



Pinch Point Position = Die Rail Height + Brake Die Height + Material Thickness + Brake Punch Height



Gen II Backgauge Programming Guide



Reference for TEACH MODE for the Ram Position

```
TEACH NEW JOB:
TEACH NEW BEND 1
TOS POSITION
XX.XXXX XX.XXXX
```

The number on the left is what the control will program.

The number on the right is where the ram is presently positioned in relation to the top of the bed.


When you press the **JOB LEARN** button, the present ram position number will be on the left, but you must press **ENTER** to accept it.

The **JOB LEARN** button takes the place of typing the number, but in either case, you must press **ENTER** to accept this number and continue on.

Gen II Backgauge Programming Guide

Gauge Finger Calibration Procedure:

1. Measure the distance from back surface of the finger body to the tip of the finger. Adjust the finger length until the two assemblies are the same dimension.
2. Ensure that the area between the back gauge carriage and the die are completely cleared of any obstructions
3. Loosen the two 5/16"-18 Socket Head Cap Screws on R-Axis Bar
4. Push/Pull Back Gauge Bar to full back position
5. Use R-Axis Hand wheels to adjust the gauge bar height so the gauging surface is aligned with the reference bars.
6. Rotate the PROG/RUN switch to the PROG position
7. Type "4" on keypad for GOTO BACK GAUGE
8. Type "4" on keypad for 4.000 inches
9. Press ENTER and the gauge bar will move to 4.000 inches
10. Change HAND/FOOT to HAND
11. Change MODE to INCH
12. Rotate the PROG/RUN switch to RUN position.
13. Place the gauge reference bars at the ends of the die with "G" facing gauge bar and carefully/slowly bring the ram down until the punch firmly clamps the "V" groove in reference bars. Do not exert too much force on the reference bars as damage may occur



14. Push Fingers forward until they touch the reference bars
15. Tighten the two 5/16"-18 Socket Head Cap Screws on R-Axis Bar
16. Type "4" on keypad for GOTO BACK GAUGE
17. Type "24" on keypad for 24.000 inches
18. Press ENTER and the gauge bar will move to 24.000 inches
19. Use RAM UP button and move ram up to remove reference bars
20. The back gauge is now calibrated

WARNING


Ensure that no part of the Finger Assembly interferes with the press brake tooling

All backgauge adjustments must be made from the rear of the machine.


Do not reach across the press brake tooling or through the bed and ram.

Severe injury or death may result if these procedures are not followed

Gen II Backgauge Programming Guide



Gen II Backgauge Programming Guide



ITEM	QTY	DESCRIPTION
23	4	0591003 SSS #6-32 X 1/4
22	2	T3215 T-SLOT BOLT, 3/8-16 X 1 LG
21	2	053025 SHCS 5/16-18 X 1-1/2
20	2	T3150 BHSCS #8-32 X 1/2
19	2	T0694 ROLL PIN 1/8 X 1-1/2
18	8	053031 SHCS 5/16-18 X 1
17	8	053039 SHCS 3/8-16 X 3/4
16	2	T3123 FINGER ASSEMBLY, STANDARD
15	2	T3148 SAE 841 PL BRG 3/8 X 5/8 X 1/2 LG
14	4	0530374 SAE 841 PL BRG 1 X 1-1/4 X 1 LG
13	2	T3118 R-AXIS HANDWHEEL, BACK GAUGE
12	2	T3274 THRUST WASHER, .39 X .75 X 1/32
11	1	T3287 BACK GAUGE BAR, 72" LG
10	2	0521008 FLAT WASHER 3/8", USS., PLATED
9	2	T3120 GAUGE BAR, EXTENSION
8	2	T3117 R-AXIS SCREW, STANDARD
7	2	T3146 R-AXIS NUTSERT, ALL THREAD
6	2	T3114 R-AXIS MOVING BAR, MACHINED, BG
5	2	T3113 R-AXIS TIE BAR, BACK GAUGE
4	1	T3095 TOP PLATE, CARRIAGE
3	4	T3094 WAY BAR, R-AXIS
2	4	T2713 BALL BUSHING - 1"
1	2	T3050 WAY BLOCK, MACHINED, BG, ALUMINUM

PROPERTY NOTICE
 This drawing is property of Mega Manufacturing and you may not reproduce or use it in any way without the express written consent of Mega Manufacturing. It is specifically forbidden to fabricate parts based on this drawing.

DESIGNED BY: DWS
 DRAWN BY: DWS
 DATE: 18-Jul-02
 APPROVED: [Signature]

9606

PIRANHA
 MEGA MANUFACTURING

Gen II Backgauge Programming Guide

NOTE:
 DO NOT ASSEMBLE T2713 LINEAR BUSHING INTO T3090 WITH THIS ASSEMBLY. THE BUSHING IS NOT DESIGNED TO BE USED WITH THIS ASSEMBLY. ITEM 7 INTO ITEM 6, BE SURE TO LINE UP SLOT WITH #6-32 HOLE.

ITEM	QTY.	PART #	DESCRIPTION
23	4	0591003	SSS #6-32 X 1/4
22	2	T3215	T-SLOT BOLT, 3/8-16 X 1 LG
21	2	0531025	SHCS 5/16-18 X 1-1/2
20	2	T3150	BHSCS #8-32 X 1/2
19	2	T0694	ROLL PIN 1/8 X 1-1/2
18	8	0531031	SHCS 5/16-18 X 1
17	8	0531039	SHCS 3/8-16 X 3/4
16	2	T3123	FINGER ASSEMBLY, STANDARD
15	2	T3148	SAE 841 PL BRG 3/8 X 5/8 X 1/2 LG
14	4	0531374	SAE 841 PL BRG 1 X 1-1/4 X 1 LG
13	2	T3118	R-AXIS HANDWHEEL, BACK GAUGE
12	2	T3274	THRUST WASHER .39 X .75 X 1/32
11	1	T3287	BACK GAUGE BAR, 72" LG
10	2	0521008	FLAT WASHER 3/8", USS, PLATED
9	2	T3120	GAUGE BAR, EXTENSION
8	2	T3117	R-AXIS SCREW, STANDARD
7	2	T3146	R-AXIS NUTSERT, ALL THREAD
6	2	T3114	R-AXIS MOVING BAR, MACHINED, BG
5	2	T3113	R-AXIS TIE BAR, BACK GAUGE
4	1	T3095	TOP PLATE, CARRIAGE
3	4	T3094	WAY BAR, R-AXIS
2	4	T2713	BALL BUSHING - 1"
1	2	T3090	WAY BLOCK MACHINING, BG, ALUMINUM

WEIGHT	DESCRIPTION
109 LBS.	CARRIAGE ASSEMBLY, BACK GAUGE


DRAWN BY: [] DATE: 06-NOV-02
 CHECKED BY: [] DATE: 06-NOV-02
 APPROVED BY: [] DATE: []

SCALE: 1/4
 DIMENSIONS PER: ASME Y14.5M-1994

DRAWING NO: T3096
 SHEET REV: 2 OF 2 A

Gen II Backgauge Programming Guide

T3123



- NOTE:**
1. ITEMS 10, 2 AND 5 MUST BE INSERTED INTO ITEM 1 BEFORE PRESSING ITEM 9 INTO ITEM 1
 2. PRESS ITEM 8 THROUGH TIMES 6 AND 2
 3. LEVEL ITEM 6 USING ITEM 14 SET SCREW AND LOCTITE
 4. ADJUST FINGER IN AND OUT BY TURNING ITEMS 4 AND 5 AS NEEDED. LOCK DOWN BY TURNING BOTH AGAINST EACH OTHER

ITEM	QTY	PART #	DESCRIPTION
15	2	T3179	BHCS #6-32 X 1/4
14	1	0591003	SSS #6-32 X 1/4
13	1	T3178	ADJUSTABLE LEVER, 3/8-16 X 1.77 LG
12	1	0521008	FLAT WASHER 3/8", USS, PLATED
11	1	T3198	T-NUT, 3/8 THD, 7/16 SLOT
10	1	T3294	FINGER SPRING, BACK GAUGE
9	1	T3177	SAE841 PL BRG 1/2ID 5/8ODD 1-1/4LG
8	1	T3173	DOWEL PIN 3/16 X 1
7	1	T3174	FINGER EXTENSION, BACK GAUGE
6	1	T3172	FLIP FINGER, BACK GAUGE
5	1	T3176	FINGER ADJUSTING NUT, B.G.
4	1	T3175	FINGER ADJUSTING SCREW, B.G.
3	1	T3239	FLAT WASHER, 13/32ID, 10D, 3/16THK
2	1	T3145	FINGER ROD, BACK GAUGE
1	1	T3143	FINGER BLOCK, BACK GAUGE

<p>PROPRIETARY NOTICE This drawing is property of MEGA MANUFACTURING and shall not be reproduced, copied, lent, or disposed of nor used for any other purpose than for which it is specifically furnished and must be returned upon demand.</p>	
<p>FINGER ASSEMBLY, STANDARD</p>	
DRAWN BY	DKB
DATE	16-Aug-02
APPROVED	
DATE	
DRAWING NO.	T3123
SHEET	1 of 1
REV.	B



B	ECN 02-122; ITEM 10 WAS T0050; T3145 LENGTHENED	DKB	01-Nov-02
A	ECN 02-112; ADDED ITEM #11 AND RENUMBERED.	DKB	16-Sep-02
REV	ITEM #8 WAS 3/8 ID. 1/2 OD	DATE	